



杰美康机电
JUST MOTION CONTROL

2HSS858H-N
Stepping Servo Driver
Instructions for use



Http: //www.jmc-motion.com

**Address: Building B, Jiayu Science Park, Matian Street, Guangming
District, Shenzhen**

Tel: 0755-26509689 26502268

Fax: 0755-26509289

E-mail:info@jmc-motion.com

All contents of this manual are copyrighted by Shenzhen JMC Electromechanical Co., Ltd., and no unit or individual may copy, copy or copy them without permission of Shenzhen JMC Electromechanical Co., Ltd. No warranties, positions or other implications of any kind are made in this manual. If there is any product information mentioned in this manual, the direct or indirect data flow caused by the loss of benefits, Shenzhen JMC Mechanical and Electrical Co., Ltd. and its employees do not assume any responsibility. In addition, the products mentioned in this manual and their information are for reference only and subject to update without notice.

All rights reserved.

Shenzhen JMC Electromechanical Co., Ltd.

version	prepared	approved
V1.51	Rd	Rd

目录

2HSS858H-N	1
1. Overview	5
2. Technical characteristics	5
3. Application fields	7
II. Technical indicators	8
1. Electrical, mechanical and environmental indicators	8
2. Mechanical installation size drawing	9
3. Strengthen the heat dissipation method	9
00Err Alarm Handling:	11
1、 Alarm on power-up:	11
check the wiring first, confirm that there is no short circuit between the motor adapter wire and the motor wire. Otherwise, try replacing the drive or motor.	11
2、 Alarms during operation:	11
a. Check the wiring to confirm that there is no short circuit between the motor transfer wire and the motor wire;b. Check whether there is electromagnetic interference outside;c. Reduce the speed and lengthen the acceleration and deceleration time.	11
11Err, 22Err Alarm Handling:	12
Power on again, alarm or replace the driver;	12
33Err Alarm Handling:	12
1、 Alarm on power-on: first confirm whether the power supply voltage is too high, exceeding AC 114V and DC 160 V. Verify that the voltage is OK and try replacing the drive.	12
2、 Alarm during operation: a. Check whether there is electromagnetic interference outside;b. Reduce speed and lengthen acceleration and deceleration time;	12
44Err Alarm Handling:	12
55Err Alarm Handling:	12
1, check whether the motor power line is not connected well, or poor contact.	12
2. Modify P30 to 0 and power on again.	13
EnOFF processing:	13
Check if ENA signal is connected. IV. Driver interface and wiring introduction	13
1. Interface definition	14
2. Control signal interface circuit diagram	18
3. Control signal timing diagram	20
4. Control signal mode setting	21
5. Encoder wiring	21
V. Driver parameter setting	23
VI. Parameter adjustment method	33
1.Key operation method	33
VII. Typical application wiring diagram	34
Eight, common problems and fault handling	35
1, power-on digital tube no display	35
2. Alarm after power-on or rotation of a small angle	35
3. No rotation after pulse input	35
00Err Alarm Handling:	36

1. Alarm on power-on: first check the wiring and confirm that the motor adapter wire and motor wire are not short-circuited. Otherwise, try replacing the drive or motor.	36
2. Alarm during operation: a. Check the wiring to confirm that there is no short circuit between the motor adapter wire and the motor wire;b. Check whether there is electromagnetic interference outside;c. Reduce the speed and lengthen the acceleration and deceleration time.	36
11Err, 22Err Alarm Handling:	36
Power on again, alarm or replace the driver;	36
33Err Alarm Handling:	36
1. Alarm on power-on: First confirm whether the power supply voltage is too high, exceeding AC 114V and DC 160 V. Verify that the voltage is OK and try replacing the drive.	36
2. Alarm during operation: a. Check whether there is electromagnetic interference outside;b. Reduce speed and lengthen acceleration and deceleration time;	36
44Err Alarm Handling:	36
55Err Alarm Handling:	37
1, check whether the motor power line is not connected well, or poor contact.	37
2. Modify P30 to 0 and power on again.	37
EnOFF processing:	37
Check if ENA signal is connected.	37

I. Product Profile

1. Overview

2HSS858H-N is a new simple step servo driver perfectly integrated into servo technology. The stepper servo driver adopts the latest 32-bit DSP and integrates advanced power angle closed-loop control algorithm. Compared with the traditional stepper driver, it can avoid the step loss problem to the greatest extent, effectively suppress the motor temperature rise, obviously reduce the motor vibration, and greatly enhance the motor high-speed performance. The driver cost is 50% of AC servo system, and the motor size is compatible with traditional stepping motor, which is convenient for customers to replace and upgrade. In short, this step servo driver set no lost step, low temperature rise, high speed, high torque, low cost and other advantages in one, is a cost-effective motion control products.

2. Technical characteristics

- ◆ No missing steps, accurate positioning
- ◆ 100% rated torque drive motor
- ◆ Variable current control technology, high current efficiency

- ◆ Small vibration, stable operation at low speed
- ◆ Built-in acceleration and deceleration control to improve start-stop smoothness
- ◆ User-definable segmentation
- ◆ Compatible with 1000 and 2500 line encoders
- ◆ General application parameters need not be adjusted
- ◆ Phase loss protection, over current protection, over voltage protection and over-differential protection
- ◆ Six-digit digital tube display, easy to set parameters and monitor motor running state

3. Application fields

Suitable for all kinds of automatic equipment and instruments with large torque requirements, such as engraving machine, stripping machine, marking machine, cutting machine, laser typesetting, plotter, CNC machine tool, automatic assembly equipment, etc. It works particularly well in devices where users expect low noise and high speeds.

II. Technical indicators

1. Electrical, mechanical and environmental indicators

input voltage		50~90VAC
continuous current output		6.0A
maximum pulse frequency		Can be set via internal parameters
logic input current		7~20mA (10mA typical)
default communication rate		57.6Kbps
protection		<ul style="list-style-type: none"> ● Peak value of over current action value $16A \pm 10\%$ ● Over voltage action value 200VDC ● Excessive difference alarm thresholds can be set via the driver's front panel
m ak e wi th rin	occasions	Try to avoid dust, oil mist and corrosive gases
	operating temperature	70°C max.
	storage temperature	-20°C ~ +65°C
	humidity	40~90%RH

g re al m	cooling method	Natural cooling or forced cooling
--------------------	-------------------	-----------------------------------

2. Mechanical installation size drawing




Figure 1 Mechanical installation size diagram (unit:mm)

When designing installation size, consider terminal size and ventilation and heat dissipation.








3. Strengthen the heat dissipation method

(1) The reliable working temperature of the driver is usually within 60°C , and the working temperature of the motor is within 90°C ;

(2) When installing the drive, please use vertical side

installation to form strong air convection on the surface of the radiator; if necessary, install a fan near the drive to force heat dissipation to ensure that the drive works within a reliable working temperature range.

III. Fault code

Fault display	cause of issue
	Motor overcurrent alarm
	Voltage reference alarm
	Parameter upload alarm
	Power overvoltage alarm
	Position out of tolerance alarm
	Motor phase loss alarm
	Drive offline

00Err Alarm Handling:

1、Alarm on power-up:

check the wiring first, confirm that there is no short circuit between the motor adapter wire and the motor wire. Otherwise, try replacing the drive or motor.

2、Alarms during operation:

a. Check the wiring to confirm that there is no short circuit between the motor transfer wire and the motor wire;b. Check whether there is electromagnetic interference outside;c. Reduce the speed and lengthen the acceleration and deceleration time.

11Err, 22Err Alarm Handling:

Power on again, alarm or replace the driver;

33Err Alarm Handling:

1、Alarm on power-on: first confirm whether the power supply voltage is too high, exceeding AC 114V and DC 160 V. Verify that the voltage is OK and try replacing the drive.

2、Alarm during operation: a. Check whether there is electromagnetic interference outside;b. Reduce speed and lengthen acceleration and deceleration time;

44Err Alarm Handling:

原因 1: 检查接线，电机线和编码器线，是否有接错或者接触不良；

处理方法: 保证接线接触良好及定义正确；

原因 2: 检查速度及加速度时间，速度过快和加速度时间过短，可能引起报警；

处理方法: 适当降低速度，延长加速时间；

原因 3: 检查结构及负载，结构是否有卡死，负载是否过重，可能引起报警；

处理方法: 调整结构，保证行程间顺畅，减驱负载测试；

原因 4: 以上没问题，更换电机或驱动器。

处理方法: 更换同型号产品做排除法测试。

55Err Alarm Handling:

1, check whether the motor power line is not connected well, or poor contact.

2. Modify P30 to 0 and power on again.


EnOFF processing:

Check if ENA signal is connected.

IV. Driver interface and wiring introduction

1. Interface definition

1) Brake interface (relay welded only for interface of driver model 2HSS858H-N-SC)



symbol	name	description
Br1	brake interface (Built-in relay)	
Br2		





2) Power terminal interface 1

terminal number	symbol	name	description
1	AC1	Power input L	L and N Indirect AC 50~90VAC
2	AC2	Power Input N	
3	A+	Motor A+ wiring	
4	A-	Motor A-wiring	
5	B+	Motor B+ wiring	
6	B-	Motor B-wiring	

3) Control signal port (44-pin DB head)

terminal number	symbol	name	description
1	IN1+	Input interface 1 positive	function preservati

			on
2	IN1-	Input interface 1 negative	function preservati on
3	PUL+	Pulse input positive	Compatible with 5V and 24V
4	PUL-	pulse input negative	
5	DIR+	Direction input positive	Compatible with 5V and 24V
6	DIR-	Direction input negative	
7	ALM+	Alarm output positive	
8	ALM-	Alarm output negative	
9	PENDING+	Position signal output positive	
10	PENDING-	Position signal output negative	
11	ENA+	enable input positive	Compatible with 5V

12	ENA-	Enable input negative	and 24V
13	OUTZ+	encoder Z phase positive	
29	OUTZ-	Encoder Z phase negative	
14	OUTB+	Encoder B phase positive	
15	OUTB-	Encoder B phase negative	
32	BRAKE+	Brake signal positive	
31	BRAKE-	Brake signal negative	
44	OUTA+	Encoder A phase positive	
30	OUTA-	Encoder A phase negative	

4) status indication

(1) Key panel: (composed of 4 keys plus 5 LED displays)



2HSS858H-N uses LED to indicate power supply and six-digit digital tube to display status. The operation of digital tube panel is shown in the table below.

key symbol	illustrate
M key	Undo exit, function switching function
ENT key (short press)	Shift function
ENT key (long press)	OK, save function
▲	Adjust parameters and add functions
▼	Parameter adjustment, reducing functions

Select the display mode by pressing "M", and select the status of monitoring motor operation by pressing up and down keys. The following table shows the meaning represented by each monitoring code.

LED display	meaning
-------------	---------

d0-Sr	Reference Speed
d1-SF	feedback speed
d2-Er	position error
d3-Pr	given position
d4-PF	position feedback
d5-u.	bus voltage
d6-Ld	given current
xxErr	drive failure
EnOFF	Drive offline

Description: Switch to this function through 'M'; i.e. parameter display function; long press 'ENT' key to view parameter value (power-on display is the parameter value you finally view), press '▼' key or '▲' key to switch function; (' key is invalid) Exit this function and go to the next function Press 'M' key.

2. Control signal interface circuit diagram

Control signal input and output interface circuit diagram, as shown in the figure below.




Figure 2 Differential signal connection




Figure 3 Common anode connection




Fig. 4 Common cathode connection

Note:Control signal levels are compatible with 5V and 24V.

3. Control signal timing diagram

To avoid some misoperations and deviations, PUL, DIR and ENA should meet certain requirements, as shown in Figure 3 below:




Figure 5 Control Signal Timing Diagram

Notes:

- (1) t_1 : ENA (enable signal) shall be determined high at least $6\mu s$ ahead of DIR. ENA+ and ENA- are generally recommended.
- (2) t_2 : DIR determines its status high or low at least $5\mu s$ ahead of PUL falling edge.
- (3) t_3 : pulse width is at least $2.5\mu s$.
- (4) t_4 : Low level width is not less than $2.5\mu s$.
- (5) t_5 : DIR lags PUL rising edge by at least $5\mu s$ to maintain its state high or low.

4. Control signal mode setting

Pulse trigger edge selection: Set the pulse rising edge or falling edge trigger valid through the driver's front panel.

5. Encoder wiring

Encoder wiring is provided by our 15-pin extension cable

and motor encoder cable, which connects directly to the motor and driver without customer wiring. The following table shows the 2HSS 858H-N encoder interface definitions.

DB header pin	signal	described
1	EA+	Encoder Channel A Input Positive
2	EB+	Encoder B channel input positive
3	GND	Encoder input GND
11	EA-	Encoder Channel A Input Negative
12	EB-	Encoder Channel B Input Negative
13	VCC	Encoder power input +5V

V. Driver parameter setting

2HSS 858H driver parameter setting method: parameters can be set through the front panel of the driver. There is a set of default factory configuration parameters corresponding to the best motor inside the driver. Users only need to adjust the internal subdivision number of the driver according to the specific use situation. See the following table for specific parameters and functions:

Actual value of parameter = set value × corresponding dimension

serial number	name	range	dimensional	restart drive	default parameters
P1	Current loop proportional gain	0-9000	0.0001	is	1000
P2	Current loop integral gain	0-2000	0.0001	no	100
P3	actuator	0-1000	0.0001	no	50

	damping coefficient				
P4	position loop proportional gain	0-5000	0.001	no	2000
P5	position loop integral gain	0-1000	0.01	no	200
P6	speed loop proportional gain	0-5000	0.00001	no	300
P7	velocity loop integral gain	0-1000	0.00001	no	1000
P8	Driver open-loop current	0-60	0.1	no	40
P9	Driver closed-loop	0-40	0.1	no	20

	current				
P10	Driver alarm level	0-1	1	is	1
P11	driver direction level	0-1	1	no	1
P12	pulse edge selection	0-1	1	is	0
P13	Driver enable level	0-1	1	is	0
P14	Driver bit level	0-1	1	is	1
P15	Encoder line number selection	0-1	1	is	0
P16	Drive position out of tolerance	0-3000	10	no	400
P17	Drive subdivision options (shown in	0-15	1	is	2

		the table below)						
parameters	0	1	2	3	4	5	6	7
number of divisions	Custom subdivision	800	1600	3200	6400	12800	25600	51200
parameters	8	9	10	11	12	13	14	15
number of divisions	1000	2000	4000	5000	8000	10000	20000	40000
P18	proportiona l coefficient	0-10000		0.01		no		100
P19	driver command smoothing	0-10		1		no		2
P20	User-define d segmentatio n	0-1000		50		is		8
P21	Driver power-on display	0-4		1		no		0
P22	back electromoti ve force compensati on	0-10000		0.01		no		100

	coefficient				
	Drive				
P23	Enable	0-1	1	is	0
	Lock				
	open-loop				
	angle				
P24	compensati	0-10000	0.0001	no	0
	on				
	Open-close				
	d loop				
P25	superpositio	0-100	1	no	20
	n ratio				
	bit output				
P26	threshold	0-4000	1	no	10
	Open-close				
	d loop mode				
P27	selection	0-1	1	is	1
	factory	reservatio	reservation		reservatio
P28	parameters	ns	s		ns
	factory	reservatio	reservation		reservatio
P29	parameters	ns	s		ns
	Driver				
P30		0-1	1	is	1

	phase loss detection				
P31	PWM mode	0-9000	1	is	0
P32	factory parameters	reservatio ns	reservation s		reservatio ns
P33	factory parameters	reservatio ns	reservation s		reservatio ns
P34	half-flow slope	0-10	0.00001	no	30
P35	half-flow downtime	0-1500	10	no	1000
P36	shutdown threshold	0-4000	1	no	100
P37	shutdown current setting	0-60	0.1	no	25
P38	shutdown half-flow enable	0-1	1	no	1
P39	PWM arrangemen t	0-2	1	is	0

	Overvoltage				
P40	judgment time current	0-4000	200	no	200
P41	variation threshold current	0-4000	1	no	10
P42	variation limit directional	0-4000	1	no	50
P43	hysteresis selection	0-1	1	is	1

There are 43 parameters, which can be modified via the front panel of the drive. The parameter settings are described below:

Parameters P1, P2, P3, P4, P5, P6, P7 are used to set the parameters of current loop, system damping, position loop and velocity loop respectively.

Parameters P8 and P9 are used to set open-loop current and closed-loop control current respectively. (Actual current = open loop current + closed loop current)

Parameter P10 is used for alarm output level selection. Parameter 1 indicates that the optocoupler output transistor

is off during normal operation; the optocoupler output transistor is on during driver alarm. And vice versa.

Parameter P11 is used for directional level selection. By setting this parameter, the control direction of the control terminal level can be changed.

Parameter P12 is used for pulse edge selection. By setting this parameter, the effective edge of pulse can be changed.

Parameter P13 is used to select the level of the enable signal, generally 0, low level enable, that is, no external enable input signal is required. And vice versa.

Parameter P14, select the position output level, 1 means that the driver meets the position condition when the optocoupler output transistor is turned off; when the position condition is not met, the optocoupler output transistor is turned on. And vice versa.

Parameter P15, line number selection of encoder, 0 means 1000 lines, 1 means 2500 lines.

Parameter P16 sets the threshold for position deviation.
(Actual = setpoint × 10)

Parameter P17, Subdivision setting of drive

parameters	0	1	2	3	4	5	6	7
number of divisions	Custom subdivision	800	1600	3200	6400	12800	25600	51200
parameters	8	9	10	11	12	13	14	15

number of divisions	1000	2000	4000	5000	8000	10000	20000	40000
----------------------------	------	------	------	------	------	-------	-------	-------

Tip: In addition, the driver also provides the user with any subdivision that can be freely set, and the specific parameters are set by **mode P20**.

Parameter P19, Command Smoothing Coefficient




Figure 7 Command smoothing coefficient

Parameter P20 is used for user-defined subdivision number. The user-defined subdivision value is $P20 * 50$. For example, the user needs to set the subdivision to 6100. First, set $P17=0$, and then set $P20=122$.

Parameter P21, driver power-on display.

parameter	0	1	2	3	4
s					
display	Reference	feedback	position	reference	feedback
informati	Speed	speed	error	position	position
on					

Parameter P23, **driver enable lock**, when this parameter is 0, after the enable signal is given, the motor does not lock the shaft, and the driver does not count external pulses. When this parameter is 1, given the enable signal, the motor locks the

shaft and the driver does not count external pulses.

Parameter P27, **open-closed loop mode selection**, when this parameter is 0, it is open-loop mode. When this parameter is 1, it is closed loop mode.

Parameter P30, **driver phase loss detection**, 1 means ON, 0 means OFF. Limited to manufacturer maintenance.

VI. Parameter adjustment method

1. Key operation method




Figure 8 Flow chart of key operation

Note: ENT key short press for shift, long press for confirmation.

The default parameters of current ring, position ring and speed ring of the driver are the best parameters of the matching motor. Customers generally do not need to modify them. They only need to select the motor subdivision number and the percentage of open and closed loop current according to the needs of system control.

VII. Typical application wiring diagram

A typical wiring diagram consisting of a 2HSS858H-N driver, etc. is shown in Figure 8. AC50~90V is selected according to the voltage class of matching motor.




Figure 11 Typical wiring diagram

Note: Resistor R of in-place output and alarm output port is connected to control signal terminal, with resistance value of 3~5K.

Eight, common problems and fault handling

1, power-on digital tube no display

- Input power failure, please check the power line. Is the voltage too low?

2. Alarm after power-on or rotation of a small angle

- Check whether the motor feedback signal wire and motor power phase wire are connected
- Step servo driver input power supply voltage is too high or too low
- Whether the phase sequence of motor is connected correctly. Incorrect Please refer to the motor identification and drive corresponding phase sequence connection
- In the drive configuration parameters, whether the motor encoder wire number is consistent with the actual parameters connected to the motor. Reset if different
- Whether the pulse input speed is greater than the rated speed of the motor, and the position exceeds the tolerance.

3. No rotation after pulse input

- Is the wiring of the pulse input terminal of the step servo driver reliable?
- Is the input mode in the step servo driver system configuration pulse input dependent input mode
- Does the motor enable release

00Err Alarm Handling:

1. Alarm on power-on: first check the wiring and confirm that the motor adapter wire and motor wire are not short-circuited. Otherwise, try replacing the drive or motor.

2. Alarm during operation: a. Check the wiring to confirm that there is no short circuit between the motor adapter wire and the motor wire;b. Check whether there is electromagnetic interference outside;c. Reduce the speed and lengthen the acceleration and deceleration time.

11Err, 22Err Alarm Handling:

Power on again, alarm or replace the driver;

33Err Alarm Handling:

1. Alarm on power-on: First confirm whether the power supply voltage is too high, exceeding AC 114V and DC 160 V. Verify that the voltage is OK and try replacing the drive.

2. Alarm during operation: a. Check whether there is electromagnetic interference outside;b. Reduce speed and lengthen acceleration and deceleration time;

44Err Alarm Handling:

Reason 1: Check the wiring, motor wires and encoder wires to see if they are connected incorrectly or have poor contact;

Treatment method: Ensure that the wiring contact is good and the definition is correct;

Reason 2: Check the speed and acceleration time, Too fast speed and too short acceleration time may cause an alarm;

Treatment method: appropriately reduce the speed and extend the acceleration time;

Reason 3: Check the structure and load to see if the structure is stuck and whether the load is too heavy, which may cause an alarm;

Treatment method: adjust the structure to ensure smooth travel, and test with reduced drive load;

Reason 4: There is no problem with the above, replace the motor or driver.

Treatment method: Replace the product with the same model and do the elimination test.

55Err Alarm Handling:

1, check whether the motor power line is not connected well, or poor contact.

2. Modify P30 to 0 and power on again.

EnOFF processing:

Check if ENA signal is connected.