



3DM2060H

Digital stepper driver
User manual

Address:Building B, Jiayu Science Park, Jin'an Road, Matian Street,
Guangming District, Shenzhen China. Tel: 0755-26509689 400 189 0098
Fax: 0755-26509289 **E-mail:**info@jmc-motion.com
Http: //www.jmc-motion.com

Preface

All the content of this manual, the copyright of the work belongs to Shenzhen JMC Mechanical and Electrical Co., Ltd..

All, without the permission of Shenzhen JMC Mechanical and Electrical Co., Ltd., any unit or individual may not copy, copy, write copy at will. This manual does not have any form of guarantee, position expression or other implication. If there is information about the products mentioned in this manual, the direct or indirect data outflow caused by the consequences of profit loss, Shenzhen JMC Mechanical and Electrical Co., Ltd. and its employees do not assume any responsibility. In addition, the products and information mentioned in this manual are for reference only, and the content is subject to update without notice.

All rights reserved and
may not be reproduced.

Shenzhen JMC Electromechanical Co. Ltd.

Version	Writer	Approved
V1.10	R&D	R&D

Directory

一、 overview	5
二、 characteristic	5
三、 Port Description.....	7
3.1 Control signal input port.....	7
3.1.1 Control signal common positive connection method	7
3.1.2 Control signal differential signal connection method.....	8
3.2 Power port	9
四、 TECHNICAL INDEX	11
五、 Control signal wiring	12
5.1 Control signal single ended common anode wiring....	12
5.2 Differential wiring method for control signals.....	13
5.3 232 serial communication wiring diagram.....	14
5.4 Control signal timing diagram.....	15
六、 DIP switch setting.....	17
6.1 SW DIP Switch Description	17
6.1.1 Current dialing settings.....	错误!未定义书签。
6.1.2 Stop current setting.....	17
6.1.3 Subdivision dialing settings.....	18
七、 Error alarm and LED flashing frequency	20

八、 Installation dimensions	21
九、 Wiring diagram.....	22
十、 Parameter settings	23
十一、 Common problems and troubleshooting	29
11. 1 The power light is not on.....	29
11. 2 Power on with red light warning	29
11. 3 Does not rotate after pulse input.....	29

一、 overview

3DM2060H is a digital two-phase stepper drive that uses the latest 32-bit technology DSP for control. This digital driver peripheral is subdivided and current dialed, allowing users to Free to set according to needs, internal DSP is used to write advanced drive control algorithms, which can ensure The stepper motor operates accurately and stably in various speed ranges, with built-in subdivision calculation The method can make the motor run smoothly at low speeds; Medium to high speed torque compensation algorithm, Can maximize the torque of the motor at high and medium speeds; Parameter self-tuning calculation Method: Able to adapt to various motors and maximize motor performance; Built in smoothing Algorithms can greatly improve the acceleration and deceleration performance of motors. In short, this digital drive can Satisfied for most applications, it is a highly cost-effective motion control product.


二、 characteristic

- ◆ Parameter self-tuning and motor adaptation;
- ◆ Built in high precision, low vibration, low heat generation, and smooth low-speed operation;
- ◆ Medium and high speed torque compensation;
- ◆ Current vector control, high current efficiency;
- ◆ Built in acceleration and deceleration control to improve smoothness of start stop;
- ◆ Single and double pulse control modes can be selected;
- ◆ Memory of motor operating position;

- ◆ Input signal differential optocoupler isolation, compatible with 5V~24V;
- ◆ Users can customize segmentation;
- ◆ Overcurrent protection, overvoltage protection;
- ◆ Automatic detection, flexible selection of pulse edge counting method;
- ◆ Green light indicates operation, red light indicates protection or offline;

三、Port Description

3.1 Control signal input port



3.1.1 Control signal common positive connection method


Pin number	grade	Name	illustrate
1	PLS+	Pulse input positive	Compatible with 5V~24V levels
2	PLS-	Pulse input negative	
3	DIR+	Direction input positive	Compatible with 5V~24V levels
4	DIR-	Direction input negative	

5	ENA+		Compatible with 5V~24V levels
6	ENA-		

3.1.2 Control signal differential signal connection method


Pin number	grade	Name	illustrate
1	DIR-	Direction input negative	Compatible with 5V~24V levels
2	DIR+	Direction input positive	
3	PLS-	Pulse input negative	Compatible with 5V~24V levels
4	PLS+	Pulse input positive	

3.2 ALM signal output port



Pin number	identifying	Name	illustrate
1	ALM+	Alarm output positive	
2	ALM-	Alarm output negative	

3.3 Power port



Pin number	identifyi ng	grade	Name	illustrate


1	Motor phase line	NC	None	Motors U, V, W Phase winding	
2		U	Motor U-end		
3		V	Motor V-end		
4		W	Motor W-end		
5	source Input end	AC1	AC80V-240V		
6		AC2			
7	shield	PE	Connect shielded wire or leave it idle		

四、TECHNICAL INDEX

INPUT VOLTAGE	AC80V~240V	
continuing current	8A	
Maximum pulse frequency	200K	
Default communication rate	57.6Kbps	
protect	 Peak overcurrent action value 15A ± 10%  Overvoltage voltage action value 350VDC	
External dimensions (mm)	192×127×85	
weight	Approximately 1500g	
使用环境	occasion	Try to avoid dust, oil mist, and corrosive gases as much as possible
	operation temperature	0~70°C
	storage temperature	-20°C~+80°C
	humidity	40~90%RH
	Cooling method	Natural cooling or forced cold air

五、Control signal wiring

5.1 Control signal single ended common anode wiring




notice:

VCC is compatible with 5V~24V.

Resistance R1 is connected to the control signal terminal, with a resistance value of 3-5 K.

5.2 Differential wiring method for control signals




notice:

VCC is compatible with 5V~24V.

Resistance R1 is connected to the control signal terminal, with a resistance value of 3-5 K.

5.3 Differential wiring method for control signals




notice:

VCC is compatible with 5V~24V.

Resistance R1 is connected to the control signal terminal, with a resistance value of 3-5 K.


5.4 232 serial communication wiring diagram



Crystal Head and Foot Position	define	illustrate
1	TXD	Sender
2	RXD	receiving end
4	+5V	For external HISU only
6c	GND	Power supply ground

5.4 Control signal timing diagram

To avoid some misoperations and deviations, PUL, DIR, and ENA should meet the requirements of one Set requirements, as shown in the following figure:



explanation:

(1) T1: ENA (enable signal) should have a minimum advance DIR of $5 \mu s$. Confirm

For high. In general, it is recommended to use ENA+and ENA - for Hanging connection method.

(2) T2: At least advance PUL counting edge 6 for DIR μ Determine its status High or low.

(3) T3: Pulse width not less than $2.5 \mu S$.

(4) T4: Low level width not less than $2.5 \mu S$.

六、DIP switch setting

6.1 SW DIP Switch Description

The SW current dial settings are shown in the table below:

DIP current Valid value	SW1	SW2	SW3
1. 3A	0	0	0
1. 8A	1	0	0
2. 5A	0	1	0
3. 1A	1	1	0
3. 7A	0	0	1
4. 3A	1	0	1
5. 0A	0	1	1
5. 6A	1	1	1

6.2 Stop current setting

When the motor stops (i.e. stops giving pulses), the current can be set by SW4. Off indicates that the stopping current is reduced compared to when the motor is running normally, and on indicates that the stopping current is the same as when the motor is running normally. It is generally recommended to set SW4 to

off to effectively reduce the heating conditions of the motor and driver. The P15 parameter of the debugging board can be set to change how long the current starts to decrease after stopping the pulse, with a default value of 50ms; set up

The P16 parameter of the debugging board can change the percentage of current reduction, which defaults to a decrease 50%.

6. 3 Subdivision dialing settings


The subdivision of the drive is set by the dial switch, as shown in the table below. In addition, when the subdivision dial table cannot meet the user's needs, the user can customize subdivision through the debugging board. If the parameter P14 is set to 4-1000, the driver subdivision will be $4 * 50-1000 * 50$. When the debugging board parameter P14 is set to 0, the user can customize subdivision

The sub function fails, and the sub function is set by the toggle switch.

The SW subdivision dialing settings are shown in the table below:


DIP subdivision	SW5	SW6	SW7	SW8
Default	1	1	1	1
400	0	1	1	1
500	1	0	1	1
800	0	0	1	1
1000	1	1	0	1
1250	0	1	0	1
1600	1	0	0	1
2000	0	0	0	1
2500	1	1	1	0
3200	0	1	1	0
4000	1	0	1	0
5000	0	0	1	0
6400	1	1	0	0
8000	0	1	0	0
10000	1	0	0	0
12800	0	0	0	0

七、Error alarm and LED flashing frequency




Number of red light flashes	Alarm Description
1	Drive overcurrent
2	Internal voltage reference error in the driver
3	Driver parameter upload error
4	The power supply voltage of the driver exceeds the maximum value

八、Installation dimensions



九、Wiring diagram

The reference for 2DM2060 shown in the figure:



十、Parameter settings

Parameter setting method for 2DM2060 driver: Through the RS232 serial communication port of the HISU debugger, a dedicated debugging board is used to complete the parameter setting. There is a set of default factory configuration parameters corresponding to the best motor inside the driver, and users only need to adjust the internal parameters of the driver according to the specific usage situation, specific parameters and functions As shown in the table below:

The actual value of the parameter= set value *corresponding dimension

Serial Number	name	range	dimen sion	Restar t driver	default parameter
P0	Drive reset	0-100	1		11
P1	Current loop ratio	0-4000	1	Yes	1000
P2	Current loop integration	0-1000	1	Yes	100
P3	System damping coefficient	0-500	1	No	100
P4	First resonance point amplitude	0-100	1	No	0
P5	Phase of the first resonance point	0-100	1	No	0
P6	Reserved	0-100	1	No	0
P7	Phase of the second resonance point	0-100	1	No	0

P8	Low speed vibration damping coefficient	0-1000	1	No	30
P9	Reserved	0-100			50
P10	Enable signal level	0-1	1	No	0
P11	Reserved	0-1	1	No	1
P12	Alarm signal level	0-1	1	No	0
P13	Pulse type selection		1	Yes	0
P14	User defined segmentation	4-1000	50	Yes	0
P15	Stop Half Flow Time	0-4000	1ms	No	100
P16	Stop current percentage	0-100	1	Yes	50

P17	Instruction smoothing coefficient	0-10	1	Yes	5
P18	Position memory enable	0-1	1	Yes	0
P19	User defined motor inductance	0-100	mh	Yes	0
P20	User defined motor resistance	0-100	0.1 Ω	Yes	0
P21	Location memory results	0-128	1		0
P22	Position memory activation time	0-100	1s	Yes	5
P23	reserved				
P24	reserved				

This driver has a total of 22 parameters that can be adjusted:

Parameters P1 and P2 are used to set the proportional and integral parameters of the current loop at the moment of power on. The proportional and integral parameters of the current loop during motor operation are automatically obtained by the self-tuning algorithm. When the parameter is 500, the driver adopts self-tuning parameters. When the parameter is not equal to 500, the driver adopts set parameters.

Parameter P3 is used to adjust the system damping coefficient to enhance the torque of the motor at medium and high speeds, while also suppressing vibration.

Parameters P4, P5, P7, P8, and P9 are used to eliminate the three resonance points of the motor.

Parameters P6, reset.

Parameter P10, used for enabling level selection. 0 indicates that the enabling signal is at a high level. Yes, the motor is in offline mode. 1 indicates that the enabling signal is at a low level. The motor is in offline mode

Offline status.

Parameter P11, reset.

Parameter P12, **reset**.

Parameter P13, Used to select single and double pulse modes, 0 represents selecting single pulse mode, and 1 represents selecting double pulse mode.


Parameter P14, used for user-defined segmentation. When set to 0, it indicates the use of dials The code switch is set to subdivide, and when set to 4-1000, it indicates that the subdivided values are:

$4 * 50 \sim 1000 * 50$, for example, if P14 is set to 80, then the drive subdivision is set to $80 * 50 = 4000$ subdivision, and the subdivision set by the DIP switch does not work.

Parameter P15, used to set how long the pulse stops before the current starts to decrease.

Parameter P16, used to set the percentage of current reduction.

Parameter P17, instruction smoothing coefficient.



Parameter P18 is used to enable the position memory function, which remembers the motor phase when power is off to prevent motor vibration during the next power on. 0 indicates that the position memory function is not enabled,

1 indicates enabling the position memory functio

Parameter P19, used for users to set their own motor inductance. 0 indicates enabling the self identification algorithm to automatically identify the motor inductance, while other values indicate not enabling the identification algorithm, Using user set inductance parameters.

Parameter P20, used for users to set their own motor resistance. 0 indicates enabling self identification algorithm to automatically identify motor resistance, while other values indicate not enabling identification algorithm Method, using user set resistance parameters.

Parameter P21, used to view position memory results.

Parameter P22, Used to set how long the pulse will stop before activating the position memory function.
Parameter P23, reset.

Parameter P24, reset.

十一、Common problems and troubleshooting

11.1 The power light is not on

- Input power failure, please check the power circuit Voltage YesNo too low

11.2 Power on with red light warning

- Motor power phase line YesNo connection
- Driver input power supply voltage YesNo too high or too low

11.3 Does not rotate after pulse input

- The wiring of the pulse input terminal of the driver is YesNo reliable

- The input method YesNo in the drive system configuration is related to pulse input
- Motor YesNo enable release